

EN: HOPLINKA - USER MANUAL

INSTALLATION STEPS



1. Remove the inflation needle from its storage holder underneath the pogo stick and securely attach it to the air pump.
2. Insert the deflated ball halfway into the holder.
3. Insert the inflation needle into the ball's air valve and inflate the ball until it is fully inflated and firmly seated in the holder. Remove the pump and needle after inflation.
4. Check that the bottom support is securely attached, then pull out the locking pin.
5. Place the cover onto the ball, align the tabs with the slots, press it down firmly, and rotate it until it locks into place.
6. Push both locking clips downward to secure the cover and complete the installation.

DISASSEMBLY STEPS



1. Lift both locking clips, rotate the cover until it is unlocked, and remove it.
2. Insert the inflation needle into the ball's air valve to release the air. Once the ball is completely deflated, remove the needle.
3. Remove the deflated ball from the holder, then return the locking pin to its original position.
4. Unscrew the inflation needle from the air pump and store it in its holder underneath the pogo stick.

USAGE INSTRUCTIONS

Before Use

- Check that all parts are securely assembled and that the elastic rope, footrests, and handles are properly attached.

- Ensure that the product is suitable for the user's weight and that there are no visible signs of damage or wear.
- Use the pogo only on a flat, open, and safe surface away from obstacles, traffic, and sharp objects.

How to Use

1. Place both feet securely on the footrests.
2. Hold the handles firmly with both hands.
3. Keep your body balanced and slightly bend your knees.
4. Use your body movement to stretch and release the elastic rope, creating a bouncing motion.
5. Maintain balance while jumping and land with both feet positioned securely on the footrests.

Safety Instructions During Use

- Maximum user weight: **30 kg**.
- Before each use, ensure that the ball is properly inflated and that the cover and locking clips are securely fastened.
- Adult supervision is recommended during use.
- Wear suitable protective equipment, such as a helmet and knee and elbow protection, especially for beginners.
- Do not use the product on wet, slippery, uneven, or damaged surfaces.
- Do not perform dangerous tricks, excessive jumps, or use the product in unsafe areas.
- Stop using the product immediately if any part becomes loose, damaged, or worn.

After Use

- Store the pogo in a dry place away from direct sunlight and extreme temperatures.
- Regularly check the elastic rope and other components for damage before the next use.