EN: AUTOSHARP – USER MANUAL

PRODUCT SPECIFICATIONS

Product name: AUTOSHARP
Model number: JY-021
Input Rating: DC 5V/1A (UBS)
Battery: 3.7V 1200mAh 4.44Wh

METHOD OF OPERATION

1. Fully charge the device before first use.
2. The device can be used while charging if necessary; however, for best performance, use it when fully charged.
3. Orientation: The power switch is located on the left side, and the sharpening slots are on the right side.
4. For daily maintenance, use the **fine sharpening slot**. If the blade is very dull, first use the **coarse sharpening slot**, then finish with the fine slot for a smooth edge.
5. Do not use this device for knives that are too large or exceed the width of the sharpening slot.
6. Hold the sharpener firmly with one hand and the knife with the other. Insert the blade into the slot and pull it smoothly toward you from heel to tip. Do **not** move the blade back and forth.

CHARGING INSTRUCTIONS

1. Charge the device fully before initial use.
2. Use a **Type-C charging cable** with a 1A–2A power source.
3. Ensure the charging port remains dry and clean during charging.

DETACHABLE DESIGN



This product features a detachable design. The grinding wheel can be removed for cleaning or replacement.
Simply rotate the component to release it, allowing for easy maintenance and improved hygiene.

SUITABLE KNIFE TYPES

This sharpener is suitable for most household knives, including:

- Chef's knives
- Slicing knives
- Utility knives
- Fruit and vegetable knives
- Standard kitchen knives

SAFETY INSTRUCTIONS

1. **Do not use** this product with serrated knives or ceramic knives.
2. Ensure the battery is sufficiently charged to avoid interruptions during operation.
3. Do not operate the device continuously for more than **5 minutes**. Allow it to cool down to prevent overheating and extend motor life.
4. If the device is not used for an extended period, charge it at least **once per month** to maintain battery health.
5. Keep the device away from water and moisture to prevent damage to the motor and internal components.
6. Store the product out of reach of children to avoid injury.
7. The grinding wheel rotates at high speed. **Never insert fingers or foreign objects into the sharpening slots.**

ADDITIONAL TIPS FOR BEST RESULTS

- Clean the blade before sharpening for better performance.
- Apply light, consistent pressure—do not force the blade.
- Wipe the knife clean after sharpening to remove any metal residue.

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage tothe environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If youwant to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.