


EN: GROOMSY – USER MANUAL

PRODUCT SPECIFICATIONS:

- **Product Name:** Pet Spray Hair Comb
- **Power Input:** DC 5V/1A
- **Battery Specification:** 3.7V / 200mAh
- **Charging Time:** Approximately 90 minutes
- **Material:** ABS, Silicone
- **Suitable for:** Cats and dogs
- **Net Weight:** 147g
- **Water Reservoir Capacity:** 28ml

PRODUCT DESCRIPTION:



1. Spray Nozzle
2. Stainless Steel Needle Comb
3. Charging Port
4. Spray Switch Button
5. Hair Removal Button
6. Water Injection Port
7. Transparent Viewing Window


INCLUDED ACCESSORIES:


- 1 × Hair Comb
- 1 × Water Bottle
- 1 × User Manual
- 1 × Charging Cable

HOW TO USE:

Before using the device, ensure that the battery is sufficiently charged and that the water reservoir is filled. Follow these steps to activate the spray function:

1. **Charge the comb** – Connect the device to a power source using a DC 5V adapter. The indicator light will turn green when fully charged (see Figure 1).
2. **Fill the water bottle** – Unscrew the lid and fill the bottle with clean water (see Figure 2).
3. **Transfer water to the reservoir** – Open the small lid of the water bottle, remove the water port plug, and pour water into the comb's reservoir (see Figure 3).
4. **Activate spray function** – Press the spray switch button while combing your pet. The spray nozzle will release a fine mist (see Figure 4).
5. **Remove collected hair** – After grooming, press and hold the hair removal button to eject trapped fur, then dispose of it properly (see Figure 5).





NOTE:

When using the spray function, tilt the comb downward to ensure proper water flow to the atomizing component.

CAUTION:

- Use only a **DC 5V adapter** for charging and fully charge the device before first use.
- Clean the comb after each use with a **soft cloth or small brush**.
- **Do not wash the device with water.** Use alcohol wipes for disinfection and keep the device dry.
- **Store away from children and pets** when not in use.

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.