


## EN: IZICLIP – USER MANUAL

### PRODUCT INTRODUCTION


1. This newly designed electric hair clipper is compact and allows you to cut your hair easily and evenly. It helps you maintain short hair safely at home or on the go, offering a quick, convenient, and comfortable self-service haircut.
  2. Designed for quick, convenient, and comfortable self-haircuts anytime.
  3. Features a universal USB power supply, allowing charging via computers, power banks, mobile phones, and other USB-compatible devices, so you can recharge anytime and anywhere.
  4. Built-in high-capacity lithium battery with intelligent charging and discharging protection, including low-voltage alerts and other safety functions.
- 

### PRODUCT OVERVIEW



1. Power switch (light press)
  2. Type-C charging interface
  3. LED digital display
  4. Limit comb
  5. Limit comb locking slot
- 

### PRODUCT USE



1. Select and attach the appropriate limit comb according to the desired hair length.
2. Turn on the device using the top switch; the blue LED indicator will light up.
3. Move the clipper slowly along the scalp, following the contour of the head for an even haircut.

---

## LIMIT COMBS

The device is equipped with 2 limit combs:




- 4-position limit comb
- Adjustable limit comb (1 / 2 / 3 settings)

These allow you to create four different cutting lengths:

- 1st setting: 3 mm
- 2nd setting: 6 mm
- 3rd setting: 9.5 mm
- 4th setting: 12 mm

### Limit Comb Installation



1. Ensure the hair clipper is switched off before installation.
2. Position the comb with the teeth facing forward and place it onto the clipper head.
3. Turn clockwise to select the desired length setting, then secure it by fastening the locking mechanism.

---

## WARNINGS AND USAGE TIPS

For best results, start cutting from the back of the head and move gradually toward the front. Work in smooth, consistent strokes, focusing on one area at a time until the desired length is achieved.

After completing the entire head, use circular motions across all areas to ensure an even and uniform finish.

When cutting hair for the first time, you may notice that some hair appears longer than other sections. This is normal, as hair grows in different directions. To achieve an even result, move the clipper in multiple directions and repeat the process until all hair is trimmed to the same length.

Avoid trimming too close to the ears. Do not allow the cutting blades to come into contact with the ears to prevent injury.

---

#### **INSTRUCTIONS FOR RECYCLING AND DISPOSAL:**



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.