

EN: MEDUSAMIST – USER MANUAL


Dynamic Jellyfish Aroma Diffuser

Thank you for purchasing the MEDUSAMIST diffuser. Please read this manual carefully before use to ensure proper operation and maintenance.

PRODUCT SPECIFICATIONS

- **Product name:** MEDUSAMIST
 - **Power supply:** DC 24V / 650mA
 - **Remote control battery:** CR2025, 3V
 - **Product size:** 160 × 160 × 140 mm
 - **Material:** ABS + PP
 - **Model:** V80
 - **Net weight:** 510 g
 - **Water tank capacity:** 250 ml
 - **Spray volume:** 10–50 ml/h
 - **Standards:** GB 4706.1-2005, GB 4706.48-2009
-

PRODUCT OVERVIEW



1. Spray/Timing Button
2. Mode Switch Button
3. Light Button

4. Spray Port
 5. Water Tank
 6. Fan Blade
-

KEY FUNCTIONS

Before use, Insert the power plug into the socket at the bottom of the device. Fill the water tank carefully with clean water (preferably distilled) and add a few drops of essential aroma oil if desired. Switch the device on and select the desired mode of operation.

Spray/Timing Button

- Short press once: Golden light turns on, regular cycle spray, no timer (default).
- Short press twice: Golden light turns on, continuous spray.
- Short press three times: Device powers off.
- Long press once (while powered on): Activates 4-hour timer (indicator light on).
- Long press twice: Activates 8-hour timer (indicator light on).
- Long press three times: Cancels timer, ON indicator light turns on.

Mode Switch Button

- Active only when the device is powered on.
- Short press once: Enters fixed cycle spray mode.
- Short press twice: Activates voice control mode (sprays in response to sound intensity).

Light Button

- Short press to cycle through light modes.
 - Default: Golden light.
 - Sequence: Golden light → Colorful breathing light → Fixed color → Colorful jump → Light off.
-

IMPORTANT SAFETY NOTES

1. **Add water before use.** Do not operate the humidification function when the water tank is empty.
 2. **Do not wash directly under running water.** To clean, wipe gently with a soft cloth. Avoid water entering internal components to prevent short-circuiting.
 3. **Keep out of reach of young children.** Children under 6 years old should not use this product without supervision.
 4. **Do not tilt or invert the device** while water is inside the tank.
-

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.