



SI: MELODIKO - UPORABNIŠKI PRIROČNIK

LESTVICA ZA KALIMBO S 17 TIPKAMI



SPOZNAVANJE KALIMBE



1. Vijak
2. Zgornja matica
3. Vibracijska letvica
4. Spodnja matica
5. Cilindrična zvočna matica
6. Struna
7. Zvočna votlina
8. Votlo telo

DRŽA MED IGRANJEM KALIMBE


- Kalimbo držite z rokami tako, da položite prvo mrežno mesto (območje med palcem in kazalcem) na obe strani stranskih ploskev instrumenta. Igrajte s palcem. Uporaba nohtov lahko prepreči bolečine v rokah, poleg tega pa pripomore k bolj zvonečemu zvoku iz tipk.
- Dva prsta položite v bližino zvočne odprtine, da ustvarite zvok "WAH".
- **Spretnosti: Zvok WAH:** Za ustvarjanje tega učinka palec drsi po tipkah ali jih premetava.



KAKO BRATI NOTNI ZAPIS KTAB

- **Ktab** je oblika notnega zapisa, ki je posebej zasnovana za kalimbo. S položajem note na plošči označuje, kateri ključ je treba igrati.
- **Smer branja notnega zapisa Ktab:** Branje: od spodaj navzgor.

- a. **Crotchet:** Ključ igrajte v trajanju enega takta.
- b. **Quaver:** Kvačkanje: igranje ključa za polovico takta.
- c. **Minim:** Tonažo igrajte v trajanju dveh udarcev.
- d. **Semibreve:** Tonažo igrajte v trajanju štirih udarcev.



NAVODILA ZA NEGO

- Ko kalimbe ne uporabljate, jo shranite v originalno škatlo ali vrečko, da bo zaščiten.
- Instrumenta ne postavljajte v vlažno okolje, saj lahko vlaga povzroči rjavenje in negativno vpliva na njegovo delovanje.

ODPRAVLJANJE TEŽAV Z BRENČANJEM

- Če ena ali dve tipki brenčita, lahko to vpliva na delovanje kalimbe. To je pogosta težava, ki jo je mogoče preprosto odpraviti tako, da tipke nekoliko prilagodite levo ali desno.
- Če težava vztraja, med brenčečo tipko in mostiček vstavite majhno papirnato kartico, da odpravite težave z zvokom.



NALADITEV

- Če je za natančen ton potrebno uglaševanje, pred uporabo instrumenta poskrbite za uglaševanje tipk. Pri tem si lahko pomagate z mobilno aplikacijo za uglaševanje.
 - **Aplikacija za Android:** gStrings
 - **Aplikacija Apple:** insTuner
- Včasih lahko uglaševalniki težko prepoznajo določene tipke, zlasti v višjem visokem razponu. To se lahko zgodi zaradi resonance okoli tipke, zaradi česar uglaševalnik napačno odčita noto. Če želite to odpraviti, med uglaševanjem rahlo pritisnite tipko v levo ali desno, dokler ne dobite pravih tona.



VADBA POSAMEZNE MELODIJE




Diagram 1 shows a guitar fretboard with a 4/4 time signature. The strings are labeled E, C, A, F, D, C, E, G, B, D from left to right. Frets 1 through 5 are marked on the right. A vertical bar is drawn at fret 3. Fingering is indicated by black dots: fret 1 (E, C, A, F, D), fret 2 (C, E, G, B, D), fret 3 (E, C, A, F), fret 4 (C, E, G, B), and fret 5 (E, C, A, F). Open circles are placed on the D string at fret 3 and the E string at fret 5.

1




Diagram 2 shows a guitar fretboard with frets 9 through 12 marked on the right. A vertical bar is drawn at fret 9. Fingering is indicated by black dots: fret 9 (E, C, A, F, D), fret 10 (C, E, G, B, D), fret 11 (E, C, A, F), and fret 12 (C, E, G, B). Open circles are placed on the D string at fret 9 and the E string at fret 11.

2




Diagram 3 shows a guitar fretboard with frets 5 through 9 marked on the right. A vertical bar is drawn at fret 5. Fingering is indicated by black dots: fret 5 (E, C, A, F, D), fret 6 (C, E, G, B, D), fret 7 (E, C, A, F), fret 8 (C, E, G, B), and fret 9 (E, C, A, F). Open circles are placed on the D string at fret 5 and the E string at fret 7.

3

Del 1




Diagram 1 shows a guitar fretboard with a 4/4 time signature. The strings are labeled D, B, G, E, C, A, F, D, C, E, G, B, D, F, A, C, E from left to right. Frets 1 through 5 are marked on the right. A vertical bar is drawn at fret 3. Fingering is indicated by black dots: fret 1 (D, B, G, E, C), fret 2 (A, F, D, C, E), fret 3 (G, B, D, F, A), fret 4 (C, E, G, B), and fret 5 (D, B, G, E). Open circles are placed on the D string at fret 3 and the E string at fret 5.

1






Diagram 2 shows a guitar fretboard with frets 5 through 9 marked on the right. A vertical bar is drawn at fret 5. Fingering is indicated by black dots: fret 5 (D, B, G, E, C), fret 6 (A, F, D, C, E), fret 7 (G, B, D, F, A), fret 8 (C, E, G, B), and fret 9 (D, B, G, E). Open circles are placed on the D string at fret 5 and the E string at fret 7.

2

Del 2



"You Are My Sunshine"



IZVEDBA: NAPREDNA MELODIJA IN PETJE

《you are my sunshine》

you are my ^Csunshine my only ^Csunshine,
 you make me ^Fhappy when skies are ^Cgray.
 you'll never ^Fknow dear how much i ^Clove you.
 please don't ^Ctake my ^Gsunshine ^Caway.

C=1353

F=4616

G=5727

1. del

4/4 D B G E C A F D C E G B D F A C E

1

D B G E C A F D C E G B D F A C E

2

2. del

3

4


"You Are My Sunshine"

1


2

3

1. del




1




2

2. del





3





4



3. del



LESTVICE ZA KALIMBO Z 10 IN 15 KLJUČI



PREGLED LESTVIC ZA KALIMBO Z 10 IN 15 KLJUČI



1. Vijak
2. Zgornja matica
3. Vibracijska letvica
4. Spodnja matica
5. Cilindrična zvočna matica
6. Struna
7. Zvočna votlina
8. Votlo telo