



HR: MELODIKO – KORISNIČKI PRIRUČNIK

17-TIPKA KALIMBA SKALA



UPOZNAVANJE VAŠE KALIMBE



1. Vijak
2. Gornji most
3. Rezonantna letva
4. Donji most
5. Cilindrična rezonantna matica
6. Tipka
7. Izlaz zvuka
8. Šuplje tijelo


POLOŽAJ TIJELOM PRILIKOM SVIRANJA KALIMBE

- Držite kalimbu rukama, postavljajući prostor između palca i kažiprsta s obje strane bočnih panela instrumenta. Svirajte palčevima. Nokti mogu spriječiti bol u rukama i pomoći u stvaranju rezonantnijeg zvuka na tipkama.
- Postavite dva prsta blizu otvora za zvuk kako biste proizveli "WAH" zvuk.
- **Vještine: WAH zvuk:** Lagano klizite ili prelazite palcem preko tipki kako biste stvorili ovaj efekt.



KAKO ČITATI KTAB NOTACIJU

- **Ktab** je oblik glazbene notacije posebno dizajniran za kalimbu. Označava koju tipku treba svirati prema položaju note na notnom crtovlju.
- **Smjer čitanja Ktab notacije:** Čitajte od dna prema vrhu.
 - a. **Crotchet (Četvrtinka):** Svirajte tipku u trajanju jednog takta.
 - b. **Quaver (Osminka):** Svirajte tipku u trajanju pola takta.
 - c. **Minim (Polovinka):** Svirajte tipku u trajanju dva takta.
 - d. **Semibreve (Cijela nota):** Svirajte tipku u trajanju četiri takta.



UPUTE ZA NJEGU

- Kada ne koristite kalimbu, pohranite je u originalnu kutiju ili torbu kako bi bila zaštićena.
- Izbjegavajte postavljanje instrumenta u vlažna okruženja, jer vlaga može uzrokovati hrđanje i negativno utjecati na njegovu funkcionalnost.

KAKO POPRAVITI ZUJANJE

- Ako jedna ili dvije tipke zuje, to može utjecati na performanse kalimbe. To je uobičajen problem koji se može lako popraviti blagim pomicanjem tipki uljevo ili udesno.
- Ako problem i dalje postoji, stavite mali komad papira između zujeće tipke i mosta kako biste uklonili zvuk.



ŠTIMANJE

- Ako je potrebno štimanje za točan ton, obavezno naštimaјte tipke prije korištenja instrumenta. Možete koristiti aplikaciju za štimanje na mobilnom uređaju.
 - **Android aplikacija:** gStrings
 - **Apple aplikacija:** insTuner
- Ponekad štimeri mogu imati problema s prepoznavanjem određenih tipki, posebno u višem registru. To se može dogoditi zbog rezonancije oko tipke, što uzrokuje da štimer krivo očita notu. Da biste to popravili, lagano pritisnite tipku uljevo ili udesno dok štimajte, sve dok ne postignete točan ton.




PRAKSA JEDNOSTAVNE MELODIJE

The image shows three staves of musical notation, labeled 1, 2, and 3 from left to right. Each staff has a key signature of E , a time signature of $4/4$, and a tempo of 5 . The staves consist of vertical red bars representing notes, with black dots indicating specific note heads. Horizontal lines above the staves represent pitch levels, numbered 1 through 12 from bottom to top. The notes are primarily on the first, second, and third horizontal lines.


Dio 1

The image shows two staves of musical notation, labeled 1 and 2 from left to right. Both staves have a key signature of E , a time signature of $4/4$, and a tempo of 9 . The notation uses vertical red bars and black dots. Staff 1 starts with a note on the 4th line, followed by a note on the 3rd line, then a note on the 2nd line, and finally a note on the 1st line. Staff 2 starts with a note on the 8th line, followed by a note on the 7th line, then a note on the 6th line, and finally a note on the 5th line.

Dio 2



"You Are My Sunshine"



IZVOĐENJE: NAPREDNA MELODIJA I PJEVAČKI PRATNJI

『you are my sunshine』

you are my C sunshine my only C sunshine,
you make me F happy when skies are C gray.
you'll never F know dear how much i C love you.
please don't C take my G sunshine C away.

C=1353

F=4616

G=5727


Dio 1

4/4


1

2


Dio 2




"You Are My Sunshine"



Dio 1




1




2

Dio 2




3




4


Dio 3



10 | 15-TIPKA KALIMBA SKALE



PREGLED 10 I 15-TIPKA KALIMBE



1. Vijak
2. Gornji most
3. Rezonantna letva
4. Donji most
5. Cilindrična rezonantna matica
6. Tipka
7. Izlaz zvuka
8. Šuplje tijelo