# **EN: MINIROU – USER MANUAL**

#### **Mini Router QUICK START GUIDE**

#### **Product Overview**

Product name: MINIROU

• Battery: Rechargeable Li-ion, 3.8V, 2100mAh, 7.98Wh

• Input rating: DC 5V, 1A

• Frequency spectrum: 12.75 GHz

• Max. Radio Frequency Power: 21.5 dBm

• Keys: 1

Indicator Lights: 3

#### **Indicator Functions:**

## 1. Battery Indicator Light (red and green dual color):

- o Battery level 25%–100%: Green light remains on.
- o Battery level 10%–25%: Red light remains on.
- o Battery level below 10%: Red light flashes rapidly.

# 2. Signal Indicator Light (red and green dual color):

- o No signal: Red light remains on.
- o Signal detected: Green light remains on.
- o Internet connection active (successful dial-up): Green light flashes slowly.

## 1. Installing the SIM Card

Remove the back cover of the device and insert the SIM card according to the orientation shown on the product label.



**Important:** Before use, remove the insulation film from the battery contacts.

#### 2. Wi-Fi Connection

Press and hold the power button for approximately **6 seconds** to turn on the device. Once powered on, the green indicator light will remain steady, and it will begin to flash slowly when a user connects.

• Wi-Fi Name (SSID): 4G-MIFI-XXXX

• Password: 1234567890

# 3. Accessing the Management Interface

Connect your computer or smartphone to the device's Wi-Fi network.

Open a web browser and enter **192.168.100.1** in the address bar to access the login page.



Default Username: adminDefault Password: admin

(Note: Both username and password are lowercase.)

# 4. Changing the Wi-Fi Name and Password

From the main menu, navigate to:

# Home → WLAN Access Point Settings

Modify the Wi-Fi Name (SSID) and Password, then click Change to save your settings.



# 5. Configuring APN Settings (For Specific SIM Cards)

Some SIM cards require manual APN configuration to access the Internet.

Navigate to:

## Home → Advanced Settings → APN

Click **Add**, enter the required APN information, then select **Change** → **Set as Default** to apply the settings.



## **INSTRUCTIONS FOR RECYCLING AND DISPOSAL:**



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If youwant to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.