

EN: PEELMATIC – USER MANUAL

TECHNICAL PARAMETERS AND SPECIFICATIONS

Product Name: PEELMATIC

Model: A-920

Rated Power: 35 W


Rated Voltage: DC 3.7 V

Charging Voltage: 5 V

Charging Current: 1 A

Applicable Standards: GB4706.1-2005, GB4706.30-2008

PRODUCT COMPONENTS




1. Main unit (host)
2. Storage cover
3. Guide plate
4. Cutter head
5. Storage bowl
6. Discharge baffle

PRODUCT ASSEMBLY

- **Step 1:** Install the discharge baffle and the cutter head.
- **Step 2:** Install the guide plate. During installation, align the two holes on the guide plate with the two protruding ribs on the edge of the storage bowl.
- **Step 3:** Place the storage cover onto the storage bowl. Ensure the positioning marks on the storage cover are correctly aligned with the cylindrical part on the guide plate.

- **Step 4:** Place the main unit onto the storage cover. Ensure that the main unit and the storage cover are firmly and properly connected.



CHARGING INSTRUCTIONS

- After connecting the charging adapter, the LED indicator flashes green, indicating charging.
- When fully charged, the LED indicator remains solid green.

USER INSTRUCTIONS

1. **Preparing the fruit:** Select round or oval fruits weighing less than 150 g. Wash thoroughly, remove any foreign objects, and drain excess water.
2. **Placing the fruit:** Ensure the appliance is switched off. Open the storage cover, place the fruit inside the storage bowl, then close the cover and place the main unit securely on top.
3. **Starting the machine:** Press the power/jog switch to start the peeling process. Keep the appliance stable during operation. **Do not insert hands or allow the blade to be exposed while the device is rotating.**
4. **Finishing the process:** Once peeling is complete, press the discharge button. The fruit will automatically exit through the discharge port, and the cutter head will stop rotating. Peeling is complete.
5. **Cleaning and maintenance:** After use, clean all relevant parts promptly. Do not allow fruit residue or peel to dry on the components, as this will make cleaning more difficult.

CLEANING METHOD

1. **Main unit:** Wipe the main unit with a well-wrung damp cloth. **Do not immerse, soak, spray, or rinse the main unit with water or other liquids**, as this may cause damage or leakage.
2. **Food-contact parts:** Rinse the storage bowl and all parts that come into contact with food using clean water. Dry thoroughly by air-drying. Handle with care to avoid scratches or cuts. Wearing protective gloves during cleaning is recommended.

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.