


EN: SHAVIX – USER MANUAL

COMPONENTS OVERVIEW



1. Body hair trimmer head
2. Power switch button
3. Display screen
4. Support base
5. Shaver protective cover
6. USB charging cable
7. Cleaning brush
8. Guide comb (3–6 mm)
9. Guide comb (9–12 mm)
10. Nose hair trimmer head
11. Shaver head

SAFETY PRECAUTIONS

1. This product must not be used by children, individuals without supervision, or persons with reduced physical, sensory, or mental capabilities, or those lacking experience and knowledge.
2. If the power cord is damaged, stop using it immediately and dispose of it properly.
3. Do not plug in or unplug the charger with wet hands.
4. Keep the product out of children's reach. Do not allow children or toddlers to use it unsupervised.
5. Before use, always check if the trimmer head is damaged or broken.

CHARGING THE APPLIANCE

Warning! Do not use a fast charging adapter above 5V–1A, as it is not compatible.

Important Notes:

- Always turn off the device before charging.
 - Connect the USB cable to a 5V–1A power adapter and plug it into a power source (the charging indicator will light up).
 - The display screen will show the charging status. Unplug the charging cable once fully charged.
 - Charging time: approx. 1.5 hours.
 - Usage time: up to 70 minutes on a full charge.
 - Input: 5V–1A.
 - The device can also be charged via a computer, power bank, or mobile phone charger.
-


USER INSTRUCTIONS

Note: Before use, ensure the trimmer head is not damaged.

Travel Lock: The device is equipped with a travel lock to prevent accidental activation. Press and hold the power switch for 5 seconds to lock/unlock. The device will also unlock automatically when connected to power.

1. **Using the Body Hair Trimmer Head:**

The trimmer head comes with two guide combs (3–6 mm / 9–12 mm). It can be used for trimming hair on different body areas and can also be used without a comb for shorter trimming.



2. **Using the Shaver Head:**

Designed for trimming short hair on the armpits, legs, arms, or bikini area. Switch on the device, gently place the shaver head on the skin, and move it slowly against the direction of hair growth. After trimming, use the short guide comb for a smoother finish.

3. **Using the Nose Hair Trimmer Head:**

Suitable for safe and efficient daily care of nose hair.

CLEANING AND MAINTENANCE

- This product is IPX6 waterproof and can be rinsed under running water.
 - **Warning!** Always disconnect the power supply before cleaning.
 - Use the cleaning brush to remove residual hair from each attachment before rinsing under the faucet.
 - Allow the product to air dry. Do not wipe the blades with cotton cloth or paper towels.
 - Attach the protective cover and store the device in a cool, dry place.
-

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.