

EN: SONICRA – USER MANUAL

Thank you for purchasing SONICRA.

Please read this user manual carefully before using the device and keep it for future reference.


Specifications

- **Model:** G200
 - **Power Output:** 5W
 - **Input:** DC 5V / 500 mA
 - **Driver Size:** 40 mm
 - **Battery Capacity:** 3.7V / 300 mAh (1.11 Wh)
 - **Bluetooth Range:** Up to 10 m
 - **Dimensions:** 57 × 36 mm
 - **Functions:** Bluetooth, LED lighting, magnetic mounting
-

Package Contents


- 1 × MagBoom Speaker
 - 1 × USB Type-C Charging Cable
 - 1 × Adhesive Metal Disc
 - 1 × User Manual
-

Product Overview



1. Magnetic Base
 2. Multi-function Button (Power On/Off, Play/Pause, LED Control)
 3. USB Type-C Charging Port
-

Installation Instructions



1. **For MagSafe-compatible iPhones or cases:**
Simply align and attach the G200 speaker to the MagSafe ring on your device.
 2. **For non-MagSafe devices (e.g., Android):**
Attach the included adhesive metal disc to the back of your device. Then connect the G200 speaker magnetically to the disc.
-

Bluetooth Connection

1. Press and hold the power button for 3 seconds to turn on the speaker.
2. The LED indicator will begin flashing.
3. On your phone or Bluetooth-enabled device, search for “**G200**”.
4. Select it to pair.
5. A confirmation tone will sound once the connection is successful.

The speaker will automatically power off after 5 minutes if no Bluetooth connection is established.

Product Operation

- **Power On/Off:** Press and hold the button
- **Play/Pause:** Short press
- **Reconnect to device:** Double press
- **LED light control:** Triple press

The device will automatically shut down after 5 minutes if not connected to Bluetooth.

LED Lights

When the device is powered on, press the button three times to turn the LED lighting on or off.

Charging

1. Connect the USB Type-C cable to the charging port on the speaker.
 2. Plug the other end into a USB power source (such as a wall charger, PC, or Mac).
 3. Ensure the device is fully charged before first use for optimal performance.
-

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.