

EN: VIZICAM – USER MANUAL

Product Introduction

Thank you for choosing VIZICAM. This compact wireless security camera enables convenient monitoring and remote viewing through a smartphone application. It supports 1080p HD video recording, 2.4GHz WiFi connection, and local storage via a TF memory card.

Before use, read this manual carefully and keep it for future reference.

PRODUCT SPECIFICATIONS

Product Name: VIZICAM

Model Number: X1

Material: PC

Dimensions: 3.3 × 3.3 × 3.3 cm

Base Diameter: 3 cm

Height: 3.5 cm

Weight: 46.6 g

Camera Resolution: 1080p

Battery Lithium battery 3.7V 200mAh

Input Rating: DC 5V = 1A

Charging Port: USB-C

Memory Support: TF card up to 128GB

Wireless Frequency Band: 2.4GHz

Maximum Radio-Frequency Power: 2dBm

Product Components

The product includes the following components:

- 1x VIZICAM camera
- 1x USB-C charging cable
- 1x Magnetic base
- 1x User manual

Note: The included accessories may vary depending on the product package.

CHARGING INSTRUCTIONS

- **Before First Use:** Fully charge the camera before first use.
- **Charging Method:** Connect the USB-C cable to the camera and a suitable DC 5V, 1A power adapter.
- **Charging Safety:** Do not use damaged cables or adapters. Disconnect the charger after charging.
- **Battery Information:** The camera uses a built-in 3.7V 200mAh lithium battery. Battery life depends on usage conditions, recording settings, and network connection.

TF CARD INSTALLATION

The camera supports TF memory cards up to 128GB.

Installing and Removing the TF Card

Turn off the camera before inserting or removing the TF card. Insert the card into the TF card slot in the correct direction. After installation, the camera can use the TF card for video storage. To remove the card, turn off the camera, gently press the TF card, and remove it.

Note: Format the TF card before first use if required by the application. Regularly back up important recordings to prevent data loss.

CAMERA MOUNTING INSTRUCTIONS

The camera can be mounted using the included magnetic base.

- **Adhesive Mounting:** Remove the protective paper from the bottom of the base to expose the adhesive surface, then firmly attach the base to a clean, dry surface.
 - **Wall Mounting:** The base includes a mounting hole for screws or nails. Use suitable screws or nails to securely attach the base to a wall or other surface.
 - **Camera Attachment:** Place the camera onto the magnetic side of the base. The built-in magnet securely holds the camera in position while allowing easy removal and adjustment.
-

APP INSTALLATION INSTRUCTIONS (HDWIFICAMPRO)



App Installation on Smartphones

Download and install HDwificamPro from the Apple App Store for iOS devices or Google Play Store for Android devices. For easier installation, scan the QR code provided with the product. If your device cannot connect to Google Play, scan the APK QR code provided with the product.



Adding the Camera to the APP

1. Open the **HDwificamPro** application on your smartphone.
2. Click the "+" button to add a new camera.
3. Follow the instructions in the application to configure the camera and connect it to WiFi.
4. Enter the required WiFi information and complete the setup.
5. After successful connection, the camera will appear in the device list and can be accessed remotely.



WIFI CONNECTION NOTES

- **2.4GHz WiFi Requirement:** The camera supports only 2.4GHz WiFi networks.
- **Stable Connection:** Place the camera within a strong WiFi signal range for best performance.
- **Initial Setup:** Connect the smartphone to the 2.4GHz WiFi router before configuring the camera.

CAMERA OPERATION THROUGH THE APP

After successful connection, the HDwificamPro application allows:

- **Live Viewing:** View real-time camera images.
 - **Video Recording:** Record videos through the APP or save them to a TF card.
 - **Remote Monitoring:** Access the camera remotely through the internet.
 - **Image Adjustment:** Adjust the camera position and focus.
 - **Storage Management:** Manage recordings stored on the TF card.
-

CAMERA RESET INSTRUCTIONS

If the camera cannot connect, the password is forgotten, or a new setup is required, restore factory settings.

Reset Procedure

1. Locate the reset button on the camera.
2. Press and hold the reset button for approximately 5 seconds until the camera restarts.
3. Wait until the camera is ready for configuration.
4. Add the camera again through the HDwificamPro application.

Note: Resetting deletes previous configuration settings. The camera must be configured again after resetting.

APP FREQUENTLY ASKED QUESTIONS (FAQS)

Q1: Why can't I search for the camera or configure the network through the APP?

A: Please check the following:

- Confirm that the camera is powered on and working normally.
 - Confirm that the smartphone is connected to a 2.4GHz WiFi network.
 - Check that HDwificamPro has the required permissions enabled.
 - Restart the camera and try again.
-

Q2: Why does the camera repeatedly request a username and password or show an incorrect user message?

A: The default camera password is **6666**. If the username or password is forgotten, restore the camera to factory settings to restore the default login information.

Q3: How can I restore the camera to factory settings?

A: Press and hold the reset button for approximately 5 seconds until the camera restarts. After restarting, configure the camera again through HDwificamPro.

Q4: Why is the image blurred?

A: Check that the protective film has been removed from the lens. If the image remains unclear:

1. Carefully rotate the camera lens.
2. Adjust the focus until the image becomes clear.

INSTRUCTIONS FOR RECYCLING AND DISPOSAL:



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.