

WARNINGS AND SAFETY INSTRUCTIONS

- Read the whole manual carefully and keep it for future reference.
- Use only for intended purposes. Failure to follow user instructions may cause injury to the user or the product.
- This device is intended for household use only.
- This device can be used by children aged from 8 years and above as well as by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the device in a safe way and understand the hazards involved. Children should not play with the device. Cleaning and user maintenance should not be done by children unless they are older than 8 and supervised.
- Avoid dropping the product on the floor or otherwise damaging it.
- Do not attempt any modification or repair by yourself and ensure that any repair is conducted only by appropriately qualified technician.
- To protect against electrical shock, do not immerse appliance in water or other liquid.
- This device requires batteries to function. Insert the battery in the correct polarity and insert only the recommended battery type.
- Do not insert old and new batteries into the product at the same time.
- Do not mix standard (carbon-zinc), alkaline and/or rechargeable (nickel-cadmium) batteries.
- Please remove the exhausted batteries from the product.
- Remove batteries from the device if it will not be used for an extended period.
- Do not try to recharge non-rechargeable batteries.
- Do not short-circuit the supply terminals.
- Periodically inspect the device and batteries for signs of damage, corrosion, or leakage. Replace damaged or leaking batteries immediately.
- If the device becomes unusually hot during operation, turn it off and allow it to cool before further use. Do not use the device if there are signs of overheating, unusual odours, or smoke.
- Do not expose the battery compartment when storing this product. Remove the battery compartment only when changing batteries.
- If the surface gets dirty, please clean it with a dry or a lightly moist cloth. Do not use abrasive chemicals to clean this device.
- Do not operate the device inside the packaging.
- Store away from sources of water or moist environments. Do not store this device in direct sunlight or near sources of fire.
- **SHOCK HAZARD:** Keep your hands dry when changing the batteries. Remove the battery compartment only when changing the batteries.
- If the battery becomes severely swollen, discontinue use.

INSTRUCTIONS FOR RECYCLING AND DISPOSAL



This label means that the product cannot be disposed of as other household waste throughout the EU. To prevent potential damage to the environment or human health from uncontrolled waste disposal. Recycle responsibly to promote the sustainable use of material resources. If you want to return a used device, use the drop-off and collection system, or contact the retailer from whom you bought the product. The retailer can accept the product for environmentally safe recycling.



A declaration by the manufacturer that the product complies with the requirements of the applicable EU Directives.

OPOZORILA IN VARNOSTNA NAVODILA

- Natančno preberite celotno navodilo in ga shranite za morebitno prihodnjo uporabo.
- Uporabljajte samo za predvidene namene. Neupoštevanje uporabniških navodil lahko povzroči poškodbe uporabnika ali izdelka.
- Ta naprava je namenjena le za gospodinjsko uporabo.
- To napravo smejo uporabljati otroci, starejši od 8 let, ter osebe s fizičnimi, senzoričnimi ali duševnimi omejitvami ali pomanjkanjem izkušenj in znanja, pod pogojem, da so deležni nadzora ali navodil za varno uporabo naprave ter razumejo povezane nevarnosti. Otroci naj ne igrajo s to napravo. Čiščenje in vzdrževanje naprave naj ne izvajajo otroci, razen če so starejši od 8 let in pod nadzorom.
- Izogibajte se padcem izdelka na tla ali drugačnemu poškodovanju.
- Ne poskušajte sami spreminjati ali popravljati naprave in poskrbite, da morebitne popravke opravi ustrezno usposobljen tehnik.
- Za zaščito pred električnim šokom naprave ne potaplajte v vodo ali drugo tekočino.
- Za delovanje te naprave so potrebne baterije. Baterijo vstavite v pravilno smer in uporabljajte samo priporočeno vrsto baterije.
- Starih in novih baterij ne vstavljajte v napravo istočasno.
- Ne mešajte običajnih (cink-ogljik), alkalnih in/ali ponovno polnilnih (nikel-kadmij) baterij.
- Izdelka odstranite izčrpane baterije.
- Baterije odstranite iz naprave, če je ne boste uporabljali dalj časa.
- Ne poskušajte polniti baterij, ki niso namenjene polnjenju.
- Ne sklepajte stikov za napajanje.
- Redno pregledujte napravo in baterije glede znakov poškodb, korozije ali puščanja. Poškodovane ali puščajoče baterije takoj zamenjajte.
- Če naprava postane nenavadno vroča med delovanjem, jo izklopite in pustite, da se ohladi pred nadaljnjo uporabo. Naprave ne uporabljajte, če se pojavijo znaki pregrevanja, nenavadnih vonjav ali dima.
- Ne izpostavljajte prostora za baterije, ko shranjujete ta izdelek. Prostor za baterije odstranite le pri zamenjavi baterij.
- Če se površina umaže, jo očistite s suho ali rahlo vlažno krpo. Za čiščenje te naprave ne uporabljajte abrazivnih kemikalij.
- Naprave ne uporabljajte znotraj embalaže.
- Shranjujte stran od virov vode ali vlažnih okolij. Ne shranjujte te naprave neposredni sončni svetlobi ali blizu ognja.
- **NEVARNOST ELEKTRIČNEGA UDARA:** Ob menjavi baterij naj bodo vaše roke suhe. Prostor za baterije odstranite le pri zamenjavi baterij.
- Če postane baterija hudo otekla, prenehajte z uporabo.

NAVODILA ZA RECIKLIRANJE IN ODLAGANJE:



Ta oznaka pomeni, da izdelka ni dovoljeno odvreči med gospodinjske odpadke po vsej EU. Da bi preprečili potencialno škodo okolju ali človeškemu zdravju zaradi nekontroliranega odlaganja odpadkov. Reciklirajte odgovorno za spodbujanje trajnostne rabe materialnih virov. Če želite vrniti uporabljen izdelek, uporabite sistem za oddajo in zbiranje, ali pa stopite v stik z trgovcem, pri katerem ste izdelek kupili. Trgovina lahko sprejme izdelek za okolju prijazno recikliranje.



Izjava proizvajalca, da izdelek izpolnjuje zahteve ustreznih direktiv EU.